



Philips 2000 series
開放式真無線耳機

真無線開放式耳機

耳夾風格
播放時間長達 28 小時
藍牙多點



TAQ2000BK

耳夾風格。開放式貼合設計。

這款真無線開放式耳機可以如耳夾般佩戴，讓您享受清晰音訊和全天舒適感。兩側耳機都輕巧但牢固地夾在耳朵上，開放式設計則方便兼顧外在世界與音樂饗宴。

真無線開放式耳機。耳夾造型。

- 耳夾造型開放式耳機。舒適佩戴一整天
- 播放時間達 28 小時。薄型充電盒
- 穩定的藍牙多點連線能力

從環保出發的設計

- 從環保出發的設計和包裝
- 無塑包裝和大豆墨水
- IPX4 防潑濺且抗汗水

時髦的日常夥伴

- 清晰通話。清楚傳達您說話的內容
- 可自訂的貼耳式控制功能
- 飛利浦耳機應用程式可個人化您的耳機

PHILIPS

規格

Sound

- Frequency range: 20 - 20,000 Hz
- Speaker diameter: 12 公釐
- Impedance: 16 歐姆
- Maximum power input: 10 mW
- Sensitivity: 104 dB (1K Hz)
- Driver type: 動態

Connectivity

- Bluetooth version: 5.4
- Bluetooth profiles: HFP, A2DP, AVRCP
- Maximum range: 最多 10 m
- Multipoint connection: 是
- Supported codec: SBC

Outer Carton

- Length: 23.90 cm
- Number of consumer packagings: 24
- Width: 22.80 cm
- Gross weight: 2.640 kg
- Height: 20.00 cm
- GTIN: 1 48 95229 15918 8
- Nett weight: 1.43 kg
- Tare weight: 1.21 kg

Convenience

- Water resistance: IPX4
- Philips Headphones app support: 是
- Mono mode for TWS: 是
- Firmware updates possible: 是
- Type of controls: 按鈕

Inner Carton

- Length: 11.10 cm
- Number of consumer packagings: 3
- Width: 10.40 cm
- Height: 8.50 cm
- Nett weight: 0.18 kg
- Gross weight: 0.290 kg
- Tare weight: 0.11 kg
- GTIN: 2 48 95229 15918 5

Power

- Number of batteries: 3

- Music play time: 7 + 21 hour(s)
- Charging time: 2 hour(s)
- Fast charging time: 15 mins for 1 hour
- Battery type(Charging case): Lithium Polymer (built-in)
- Battery type(Earbud): Lithium Polymer (built-in)
- Battery weight (Total): 10.1 g
- Battery capacity(Case): 450 mAh
- Battery capacity(Earbud): 51 mAh

Packaging dimensions

- Height: 9.80 cm
- Packaging type: 紙箱
- Type of shelf placement: 吊掛式
- Width: 9.65 cm
- Depth: 3.40 cm
- Number of products included: 1
- EAN: 48 95229 15918 1
- Gross weight: 0.085 kg
- Nett weight: 0.060 kg
- Tare weight: 0.025 kg

Accessories

- Quick Start Guide: 是
- Charging case: 是

Design

- Color: 黑色
- Ear fitting: 開放式

Telecommunication

- Microphone for call: 1 mic

Dimensions

- Charging case dimension(WxDxH): 6.55 x 2.77 x 3.92 cm
- Earbud dimension(WxDxH): 2.60 x 2.70 x 1.95 cm
- Total weight: 0.048 kg

Voice assistant

- Voice assistant compatible: Apple Siri, Google 助理
- Voice assistant activation: 手動
- Voice assistant support: 是

焦點

耳夾造型開放式耳機

這款開放式耳機會輕巧但牢固地夾住外耳，還有可調式接點能讓您調整夾緊程度，享受極致舒適。精密的空氣傳導驅動器可直接將聲音傳入耳道，但不會徹底佔據聽覺，方便您同時聽見當下周遭環境的聲音。

28 小時播放時間 (7 + 21)

充飽電後可提供 7 小時的播放時間，充電盒還能再提供額外 21 小時的播放電力。如果您需要快速充電，只需將耳機放回充電盒 15 分鐘，就可以再享有一小時的電力。耳塞式耳機需要 2 小時才能充飽電，單聲道模式可讓您只使用一邊的耳機，同時為另一邊的耳機充電。

藍牙 5.4 多點連線

進階藍牙連線能力讓連線更穩定，利於順暢串流，可以同時連線兩個藍牙裝置。盡情享受播放清單，或持續不斷地收聽鍾愛的 Podcast 內容，沒有惱人的斷音。

從環保出發的設計

我們不斷地努力，讓我們的供應鏈變得更永續和透明。我們不含塑膠的包裝使用 FSC 認證的回收紙板與大豆油墨。

IPX4 防潑濺 / 抗汗水

這款真無線開放式耳機採用極輕量設計，貼合舒適，還擁有 IPX4 等級，適合每天使用。產品完全防潑水，無懼些許汗水，也不需要擔心被雨淋到。

清晰通話

通話時，清楚傳達您的聲音。專屬麥克風可接收您的聲音，而降噪演算法則可將周遭環境的一些背景雜音阻隔在外。

貼耳式控制功能

耳機上方便的按鈕功能可播放音樂、調整音量及通話。想要使用左耳機或右耳機？您可以透過飛利浦耳機輔助應用程式，自訂這些控制功能的設定方式。

飛利浦耳機應用程式

您不只可以自訂貼耳式控制功能，還可以使用我們的耳機應用程式取得最新韌體更新，管理已連線裝置，或是尋找遺失的耳機。應用程式內也有等化器供您運用。



發行日期 2025-06-26

版本 : 3.3.1

EAN: 48 95229 15918 1

© 2025 Koninklijke Philips N.V.

所有權利均予保留。

規格若有變更恕不另行通知。商標為 Koninklijke Philips N.V. 或其個別所有者的財產。

www.philips.com