

Philips
開放式無線運動耳機

開放式貼合設計

定向音效
清晰通話
雙話蓋耳鉤

TAA6708BK



擺脫束縛。盡享完整音質。

跑步，騎車，散步，愛上它！這款開放式無線運動耳機輕巧、舒適且安全，讓您在聽音樂的同時也能聽到周遭環境聲音。從公園到城市街道，將您的訓練提升到更高境界。

不同凡響

- 不使用耳機也能呈現音效。開放式設計
- 隨時準備就緒。IPX5 防水等級
- 定向音效設計
- 無論身在何處，都能享受平衡音效

完美出色

- 開放式貼合設計。輕巧、舒適、安全
- 觸控功能。簡易配對
- 飛利浦耳機應用程式。自訂音效控制等功能

讓您享受活躍生活

- 無須擔心。6+15 小時播放時間
- 充電 15 分鐘可額外提供 1 小時
- 通話音質清晰無比。室內、室外，隨時隨地

PHILIPS

規格

Sound

- Frequency range: 20 - 20,000 Hz
- Speaker diameter: 14.2 公釐
- Impedance: 16 歐姆
- Maximum power input: 10 mW
- Sensitivity: 96 dB (1K Hz)
- Driver type: 動態
- AELC 演算法：是

Connectivity

- Bluetooth version: 5.3
- Bluetooth profiles: A2DP, AVRCP, HFP
- Maximum range: 最多 10 m
- Supported codec: SBC
- 無線傳輸類型：藍牙

Outer Carton

- Length: 27.7 cm
- Number of consumer packagings: 24
- Width: 23.3 cm
- Gross weight: 4.601 kg
- Height: 29.5 cm
- GTIN: 1 48 95229 13149 8
- Nett weight: 2.376 kg
- Tare weight: 2.225 kg

Convenience

- Water resistance: IPX5
- Philips Headphones app support: 是
- Mono mode for TWS: 是
- Firmware updates possible: 是
- Type of controls: 觸覺

Inner Carton

- Length: 13.1 cm
- Number of consumer packagings: 3
- Width: 10.9 cm
- Height: 13.6 cm
- Nett weight: 0.297 kg
- Gross weight: 0.522 kg
- Tare weight: 0.225 kg
- GTIN: 2 48 95229 13149 5

Power

- Number of batteries: 3 個
- Music play time: 6 + 15 hour(s)

- Charging time: 2.5 hour(s)
- Fast charging time: 15 mins for an hour
- Battery type(Charging case): Lithium Polymer (Built-in)
- Battery type(Earbud): Lithium Polymer (Built-in)
- Battery weight (Total): 10.1 g
- Battery capacity(Case): 650 mAh
- Battery capacity(Earbud): 70 mAh

Packaging dimensions

- Height: 14.4 cm
- Packaging type: 盒子
- Type of shelf placement: 吊掛式
- Width: 12 cm
- Depth: 3.1 cm
- Number of products included: 1
- EAN: 48 95229 13149 1
- Gross weight: 0.154 kg
- Nett weight: 0.099 kg
- Tare weight: 0.055 kg

Accessories

- Quick Start Guide: 是
- Charging cable: USB-C 纜線，200 公釐

Design

- Color: 黑色
- Ear fitting: 雙軸可調整話蓋

Telecommunication

- Microphone for call: 2 AI mics

Dimensions

- Charging case dimension(WxDxH): 5.80 x 9.32 x 2.75 cm
- Earbud dimension(WxDxH): 5.18 x 3.98 x 1.55 cm
- Total weight: 0.077 kg

UPC

- UPC: 8 40063 20309 9

Voice assistant

- Voice assistant compatible: Apple Siri, Google 助理
- Voice assistant activation: 手動
- Voice assistant support: 是

焦點

6+15 小時播放時間

不想擔心每天充電的問題嗎？這款開放式耳機單次充電後，就能使用達 6 小時，適合進行多種運動計畫。如果需要額外電力，只要充電 15 分鐘，就能享有多一小時的播放時間。

通話音質清晰無比

每個耳塞式耳機中的兩個麥克風都會聚焦於您說話的聲音，並降低周遭環境的噪音。如果您身處於較安靜的地方，且不需要在通話時阻隔噪音，則單聲道模式可讓您只使用一個耳塞式耳機進行通話。

IPX5 防潑水

要在雨中中小徑上跑步？IPX5 等級代表汗水或雨水也無法阻擋這款開放式耳機，即使被弄濕，也能安全且輕鬆地充電。只要將其擦拭乾淨，然後放回充電盒即可。

輕巧、舒適、安全

為什麼要加重自身負擔？這款開放式耳機的輕巧設計讓您幾乎感覺不到它的存在，而且不會在移動時掉落。雙軸可調整話蓋能貼合您的耳形，讓耳機舒適固定。

定向音效設計

透過特殊音室與演算法，定向音效技術能將音樂傳送至耳道，將漏音與震動降至最低，同時保留細膩度與低音。具備開放式設計的所有優點，音效品質更好，佩戴更舒適。

飛利浦耳機應用程式

增強低音。調低高音。飛利浦耳機應用程式可讓您控制所聆聽的音樂。您可以自行調整音量，或是選擇預設的音效風格。

操控簡單

觸控功能讓操作變得簡單，而音效則能在啟用功能時通知您。同時支援 Siri 和 Google 助理，方便一次連接兩部裝置。非常適合用手機進行串流，並從智慧型手錶接收警示。

隨時隨地平衡音效

這款耳機採用自適應等響補償演算法 (AELC) 演算法，可調整高音及低音，因此無論是在戶外調高音量或在室內調低音量，始終能聽見清晰平衡的音效。



發行日期 2025-06-26

版本：3.0.1

EAN: 48 95229 13149 1

© 2025 Koninklijke Philips N.V.

所有權利均予保留。

規格若有變更恕不另行通知。商標為 Koninklijke Philips N.V. 或其個別所有者的財產。

www.philips.com

* 電池壽命為估計值，可能隨著應用方式不同而改變。