

PHILIPS



Professional TV

43" Studio

DVB-T2/C/S2



43HFL2889S

Keep it simple

Standalone Pro TV.

From hotel room to boardroom, give them Philips renowned picture quality with this budget-friendly standalone professional TV. Benefit from simple, lightning-fast installation and an on-screen welcome page that's easy to program.

Brilliant picture. Easy management.

- 16/7. Beautifully clear, high-contrast image
- 3 years warranty, extendable to 5 years
- Multilingual customer support
- Secure menu and control locking

Simple set up. Flexible connections.

- HDMI & VGA for PC connection.
- Instant initial USB cloning. Rapidly configure Pro TVs
- Mixed channel map to combine analogue, DVB-T/C/S channels
- Offline channel editor. Easily manage channels on a PC
- S2 satellite tuner on board

Cost-effective standalone solution

- HDMI-CEC to control external devices
- Low power consumption
- USB auto playback. Music, movies, and more

Highlights

DVB-T/C/S channels

One integrated channel list for digital (T/C/S) and analogue channels. This allows the guest to flick seamlessly between Analogue and Digital (T/C/S) channels.

Instant initial USB cloning.

Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less

than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

Control locking

By disabling or enabling the local control locking, the administrator can prevent unauthorised use of the TV via the control buttons, saving the hotelier overheads.

USB auto playback.

Share the fun. Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port on your TV to enjoy photos, videos and music with the easy to use onscreen content browser.

Low power consumption

Philips TVs are designed to minimise power consumption. This will not only reduce environmental impact but also lower operating costs.

Specifications

Picture/Display

Aspect ratio: 16:9
 Diagonal screen size (inch): 43 inch
 Diagonal screen size (metric): 108 cm
 Display: LED Full HD
 Brightness: 300 cd/m²
 Panel resolution: 1920x1080p
 Viewing angle: 178° (H) / 178° (V)

Tuner/Reception/Transmission

Digital TV: DVB-T2/C/S2, HEVC FHD (up to 1080p60)
 Analog TV: PAL, SECAM

Features

Ease of use: Picture Style, Sound Style
 Digital services: Subtitles, Teletext, MHEG, Now&Next, 8d EPG
 Local control: Joystick

Hospitality Features

Hotel mode: Joystick Control Lock, Menu lock, Installation Menu Lock, Volume limitation (incl. HP)
 Prison mode: high security mode, TXT/MHEG/USB/EPG/Subtitle Lock
 Timer: Sleep Timer, Wake Up Alarm
 Switch On control: Channel/Source, Picture Style, Volume (incl. HP)
 Anti-Theft: Kensington Lock
 Power control: Green/fast startup
 Your brand: Welcome Logo
 Cloning and Firmware update: via USB, Instant Initial Cloning
 Control: Block Automatic Channel Update
 Remote Control: Cable Strap Ready, RC Battery Door Lock
 Channels: Combined List, Off-Line Channel Editor

Healthcare features

Control: Multi-Remote Control
 Convenience: Headphone out

Multimedia

Video playback supported: Containers: AVI, MKV, Formats: H.264/MPEG4 AVC, MPEG1, MPEG2, MPEG4, HEVC, TS
 Music formats supported: MP3, AAC, WAV, WMA (v2 up to v9.2)
 Subtitle formats supported: SRT, SSA SUB, ASS, SMI, TXT
 Picture formats supported: BMP, JPG, PNG
 Supp. Video Resolution on USB: up to 1920x1080p@30Hz
 Multimedia connections: USB

Audio

Sound output Power: 16 (2x8) W
 Speakers: 2.0, Down Firing
 Sound Features: Equalizer, Balance, AVL, Incredible surround, Dynamic Bass

Power

Mains power: AC 220-240V; 50-60Hz
 Ambient temperature: 5 °C to 45 °C
 Standby power consumption: <0.3 W
 Energy Label Class: A++
 Eu Energy Label power: 37 W
 Power Saving Features: Eco mode
 Annual energy consumption: 54 kW·h

Accessories

Included: Remote Control 22AV1407A/12, 2x AAA batteries, Tabletop Stand, Warranty Leaflet, Legal and Safety brochure
 Optional: Setup RC 22AV9574A/12, Easy RC 22AV1601B/12

Connectivity Side

Common Interface Slot: CI+ 1.3
 Headphone out: Mini-Jack
 USB1: USB 2.0
 AV input: CVBS+L/R (Cinch)

Connectivity Rear

Scart: CVBS, RGB, SVHS
 Antenna: IEC-75, F-Type
 HDMI1: HDMI 1.4, ARC
 Digital Audio out: Optical
 VGA input: 15 pin D-sub
 HDMI2: HDMI 1.4

Connectivity Enhancements

EasyLink (HDMI CEC): One touch play, System Standby, RC pass through

Design

Colour: Black

Dimensions

Product weight: 8.3 kg
 Set Width: 971 mm
 Set width (with stand): 971 mm
 Wall mount compatible: M6, 200 x 200 mm
 Set Height: 571 mm
 Set Depth: 43/73 mm
 Set height (with stand): 625 mm
 Set depth (with stand): 235 mm
 Product weight (+stand): 9.2 kg

