

PHILIPS

Instant water filter

Micro X-Clean Instant filter

Usage-based filter monitor

Fits in fridge door

Type-C USB rechargeable

AWP2980WH



Next-generation instant water filter

2X more filtered water, 4X faster*

Powered by the highly porous activated carbon fibre, Philips Micro X-Clean Instant filter turns tap water into crisp and pure-tasting water by reducing chlorine, lead, pesticide and microplastics.

Thoughtful design for your convenience

- 3 L large volume water tank
- Type-C USB rechargeable

Crisp and pure-tasting water

- Turns tap water into crisp and pure tasting water

Made easy

- Flip top lid for single-handed refill
- Instant filtration with a simple touch
- Usage-based filter lifetime indicator

Good for you and good for the environment

- Prolongs the lifetime of kitchen appliances
- Delicious water at a fraction of the cost of bottled water

Highlights

3 L large volume water tank

Less frequent refill — up to 3 L of water per refill, which is 2 x of a pitcher*

Easy fill lid

Flip top lid for single-handed refill.

Economical and eco-friendly

Great-tasting water at a fraction of the cost and waste of bottled water.

Micro-X-Clean Instant filter

Powered by the innovative activated carbon fibre, which has more efficient absorption due to its highly porous structure, Micro X-Clean Instant filter achieves 4 x faster flow than a filter pitcher*, while maintaining the same filtration performance.

Prevents limescale build-up

Prolongs the lifetime of kitchen appliances by preventing limescale build-up.

Touch activation

Fresh water enjoyed instantly, at the simple touch of a button.

Type-C USB rechargeable

Rechargeable with type C USB cable, each fully recharge last up to 1 month battery life.

Usage-based filter monitor

Dual filter-replacement signal system based on actual filtration volume and usage period.

Specifications

Filtration performance

Microplastics reduction

Applicable conditions

Rated power: 6 W

Rated voltage: 5 V

Input water conditions

Input water quality: Mains tap water

Input water pressure: (atmospheric) 0-1 Bar

Input water temperature: 2-38 °C

General specifications

Filter lifetime: 1 month

Colour: Bright white

Replacement filter cartridge: AWP225

Product Dimensions (LxWxH): 233*152*263 mm

Water flow rate: 1 L/min*

Water tank capacity: 3L

Filter quantity: 1-pack

Battery capacity: 1800 mAh

Battery: Rechargeable lithium battery

Country of origin

Filter cartridge: Made responsibly in China

Instant water filter: Made responsibly in China

